

Test Report. Standard Test Method for Efficacy of Antimicrobial Agents Against Viruses in Suspension. Feline Immunodeficiency Virus.

Test Laboratory

BluScientific Test Data

School of Life Sciences
Glasgow Caledonian University
GLASGOW
G4 0BA

Identification of sample

Name of the product	SAFE 4
Manufacturer	SAFE SOLUTIONS LIMITED.
Date of Delivery	10.2.06
Storage conditions	Room temperature and darkness.
Product diluent	Sterile Hard Water
Active substances	No Known.

Test Method and its validation

Method	SAFE 4 was diluted and 0.8 ml mixed with 0.2 ml virus suspension (DMEM + 5% FBS); Dilution-neutralization. Virus CPE detected by antibody staining.
Neutralizer	Eagles minimal essential medium + 5% v/v foetal bovine serum at 4°C.

Experimental Conditions

Period of analysis	21 st – 28 th JULY 2006
Product diluent used	Sterile Hard Water
Product test concentrations	1.0 % V/V; 2.0 % V/V; 5.0 %V/V.

Contact times	5 minutes ± 10s
Test temperature	20°C ± 1 °C
Interfering substance	0.6 g/l foetal bovine serum
Stability of mixture	Precipitate absent throughout the test
Temperature of incubation	37 °C ± 1 °C + 5% CO ₂
Identification of virus	FELINE IMMUNODEFICIENCY VIRUS/CRFK CELLS

Test Result (See table 1)

Conclusion.

SAFE 4 retains virucidal activity at 5 minutes, at 2 % V/V and 5% V/V. (reduction in viral viability, 3.10 and 3.2 0 Log₁₀ respectively). contact at 20°C under clean conditions (0.6 g/l. protein as foetal bovine serum) for suspensions of Feline Immunodeficiency Virus.

